



CONTROL SHEET

X-TENSO 2 telescopic ladder

Reference: 00094_8xx



Control date:	Site:	Date on the standardised label:
Inspector name:	Address:	



Perform a visual inspection before each use Carry out a formal control every 6 months in the check sheet Before the inspection, isolate and secure the product	CONFORMITY	
General inspection of the product: Perform a visual inspection of the overall state of the product folded out and back	YES	NO
Note the marking date of the product as indicated on the standardised label (day / month / year) Example: 24/01/2020	☐	☐
Visually inspect any deformation of the rungs, ladders or base*	☐	☐
*Only on 00094_832 / 838 / 844		
Check that all footpads are present and not worn 1	☐	☐
Check that the base folds out and back (only on 00094_832 / 838 / 844) 2	☐	☐
Check that the safety labels are present (standard + pictograms) 3	☐	☐
Check that the folded up retaining strap is present and operates as intended 4	☐	☐
Check that the lock release buttons operate as intended 5	☐	☐
Check that the rungs do not turn	☐	☐
Visually inspect the sliding zones 6	☐	☐
Check when deploying, that the rungs lock and that the green indicator is displayed 7	☐	☐
Check when deploying that the base locks in the open position (Only on 00094_832 / 838 / 844)	☐	☐
Product conclusions: suitable ☐ to be repaired ☐ to be retired ☐		
For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category): https://www.tubescal-comabi.com/fr/centre-de-documentation		
Date of next check:		

** Repairs must be performed by a qualified person. The product must be checked after repair.

