



CONTROL SHEET

Pronor single ladder

Reference: 01210 5xx



Control date:	Site:	Control markings:
Inspector name:	Address:	



Perform a visual inspection before each use Carry out a formal control every 6 months in the check sheet Before the inspection, isolate and secure the product		CONFORMITY	
General inspection of the product: Perform a visual inspection of the overall state of the product		YES	NO
Note the marking date of the product on the inner side of the upright (year - day number) Example: 2020 - 032	1	☐	☐
Check there are no damaged profiles and/or components (impacts, perforation, ...)		☐	☐
Check that all fittings (screws, rivets) are correctly tightened or in place		☐	☐
Visually inspect crimping (ladder-rung assembly) and that the rungs do not turn	2	☐	☐
Check that the ladder does not become dislocated		☐	☐
Check that the two hooks are present and correctly fitted (only if hooks option)	3	☐	☐
Check that the base is present and correctly fitted (only on 02410 212 / 214 / 216 / 218 / 220 / 223)	4	☐	☐
Check that footpads are present and in good condition	5	☐	☐
Check that the safety labels are present	6	☐	☐
Product conclusions: suitable ☐ to be repaired ☐ to be retired ☐			
For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category): https://www.tubesca-comabi.com/fr/centre-de-documentation			
Date of next check:			

** Repairs must be performed by a qualified person. The product must be checked after repair.

