



CONTROL SHEET

Basic aluminium ladder

Reference: 02210 1xx



Control date:	Site:	Control markings:
Inspector name:	Address:	



Perform a visual inspection before each use
Carry out a formal control every 6 months in the check sheet
Before the inspection, isolate and secure the product

CONFORMITY

General inspection of the product:

Perform a visual inspection of the overall state of the product

Note the marking date of the product on the inner side of the upright (year - day number)

Example: 2020 - 032

1

YES NO

☐
☐

Check there are no damaged profiles and/or components (impacts, perforation, ...)

☐
☐

Check that all fittings (screws, rivets) are correctly tightened or in place

☐
☐

Visually inspect crimping (ladder-step assembly) and check that the steps do not turn

2

☐
☐

Check that the ladder does not become dislocated

☐
☐

Check that the two hooks are present and correctly fitted (only if hooks option)

3

☐
☐

Check that footpads are present and in good condition

4

☐
☐

Check that the safety labels are present

5

☐
☐

Product conclusions: suitable ☐ to be repaired ☐ to be retired ☐

For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category):
<https://www.tubesca-comabi.com/fr/centre-de-documentation>

Date of next check:

** Repairs must be performed by a qualified person. The product must be checked after repair.

