



# CONTROL SHEET

## MAXIBAT stepladder

Reference: 02375 1xx



|                       |                |                             |
|-----------------------|----------------|-----------------------------|
| Control date: .....   | Site: .....    | Control On the label: ..... |
| Inspector name: ..... | Address: ..... |                             |

|                                                                                                                                                                                                                                                                      | Perform a visual inspection before each use<br>Carry out a formal control every 6 months in the check sheet<br>Before the inspection, isolate and secure the product |                          | CONFORMITY |    |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|------------|----|
|                                                                                                                                                                                                                                                                      | YES                                                                                                                                                                  | NO                       | YES        | NO |
| <b>General inspection of the product:</b><br>Perform a visual inspection of the overall state of the product                                                                                                                                                         |                                                                                                                                                                      |                          |            |    |
| Note the marking date of the product on the inner side of the upright (year - day number)<br>Example: 2020 - 032 <span style="float: right;">1</span>                                                                                                                | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check there are no damaged profiles and/or components (impacts, perforation, ...)                                                                                                                                                                                    | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that all fittings (screws, rivets) are correctly tightened or in place                                                                                                                                                                                         | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Visually inspect crimping (ladder-step, ladder-reinforcement and ladder-platform assemblies) and that the steps do not turn <span style="float: right;">2</span>                                                                                                     | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the stepladder does not become dislocated                                                                                                                                                                                                                 | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the two hinges are present, correctly fitted and operate as intended <span style="float: right;">3</span>                                                                                                                                                 | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the tool tray is present and in good condition <span style="float: right;">4</span>                                                                                                                                                                       | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the platform is present, correctly fitted and in good condition <span style="float: right;">5</span>                                                                                                                                                      | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the handrails are present, correctly fitted and in good condition (only for handrail option) <span style="float: right;">6</span>                                                                                                                         | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the straps are present and not torn (only on 02375 107 / 108 / 109 / 110) <span style="float: right;">7</span>                                                                                                                                            | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that footpads are present and in good condition <span style="float: right;">8</span>                                                                                                                                                                           | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
| Check that the safety labels are present <span style="float: right;">9</span>                                                                                                                                                                                        | <input type="checkbox"/>                                                                                                                                             | <input type="checkbox"/> |            |    |
|                                                                                                                                                                                                                                                                      |                                                                                                                                                                      |                          |            |    |
| <b>Product conclusions:</b> suitable <input type="checkbox"/> to be repaired <input type="checkbox"/> to be retired <input type="checkbox"/>                                                                                                                         |                                                                                                                                                                      |                          |            |    |
| For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category):<br><a href="https://www.tubescacomabi.com/fr/centre-de-documentation">https://www.tubescacomabi.com/fr/centre-de-documentation</a> |                                                                                                                                                                      |                          |            |    |
| <b>Date of next check:</b>                                                                                                                                                                                                                                           |                                                                                                                                                                      |                          |            |    |
| ** Repairs must be performed by a qualified person. The product must be checked after repair.                                                                                                                                                                        |                                                                                                                                                                      |                          |            |    |

