



CONTROL SHEET

Form panel PLATFORM

Reference: 02377 30x



Control date:	Site:	Control 1 On the label:
Inspector name:	Address:	



Perform a visual inspection before each use Carry out a formal control every 6 months in the check sheet Before the inspection, isolate and secure the product	CONFORMITY	
	YES	NO
General inspection of the product: Perform a visual inspection of the overall state of the product		
Check there are no damaged profiles and/or components (impacts, perforation, ...)	☐	☐
Check that all fittings (screws, rivets) are correctly tightened or in place	☐	☐
Visually inspect crimping (ladder-step assembly) and check that the steps do not turn 2	☐	☐
Check that the platform does not become dislocated	☐	☐
Check that the steps are present, correctly fitted and in good condition 3	☐	☐
Check that the platform and toeboards are present, correctly fitted and in good condition 4	☐	☐
Check that the stabilisers are present, correctly fitted and operate as intended 5	☐	☐
Check that the rails are present and correctly fitted 6	☐	☐
Check that the guardrails are present, correctly fitted and in good condition and that the gate(s) operates as intended 7	☐	☐
Check that the lifting rings are present and correctly fitted 8	☐	☐
Check that the transport wheels are present, correctly fitted and in good condition 9	☐	☐
Check that footpads are present and in good condition 10	☐	☐
Check that the safety labels are present 11	☐	☐
Product conclusions: suitable ☐ to be repaired ☐ to be retired ☐		
For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category): https://www.tubescal-comabi.com/fr/centre-de-documentation		
Date of next check:		

** Repairs must be performed by a qualified person. The product must be checked after repair.

