



CONTROL SHEET

MODUL ALU stepladder

Reference: 02379 83x



Control date:	Site:	Control On the label:
Inspector name:	Address:	



Perform a visual inspection before each use Carry out a formal control every 6 months in the check sheet Before the inspection, isolate and secure the product	CONFORMITY	
	YES	NO
General inspection of the product: Perform a visual inspection of the overall state of the product		
Note the marking date of the product on the inner side of the upright (year-day number) Example: 2020 - 032	☐	☐
Check there are no damaged profiles and/or components (impacts, perforation, ...)	☐	☐
Check that all fittings (screws, rivets) are correctly tightened or in place	☐	☐
Visually inspect fittings (ladder-step, ladder-reinforcement and ladder-platform assemblies), that the steps do not turn and that the platform spacers are present	☐	☐
Check that the stepladder does not become dislocated	☐	☐
Check that the steps are present, correctly fitted and in good condition	☐	☐
Check that the reinforcements are present, correctly fitted and in good condition	☐	☐
Check that the platform is present, correctly fitted and in good condition	☐	☐
Check that the handrail(s) is present and correctly fitted (only for handrail option)	☐	☐
Check that the retractable guide wheels are present, correctly fitted and operate as intended (only for retractable guide wheels option)	☐	☐
Check that footpads are present and in good condition	☐	☐
Check that the safety labels are present	☐	☐
Product conclusions: suitable ☐ to be repaired ☐ to be retired ☐		
For spare parts, see the after-sales sheet available online in the "Documentation Centre" tab (After-sales split views category): https://www.tubescalcomabi.com/fr/centre-de-documentation		
Date of next check:		

** Repairs must be performed by a qualified person. The product must be checked after repair.

